



NOTES:


1. SEE CURLEX® SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.




CHANNEL INSTALLATION METHOD "A"
NO SCALE




CHANNEL INSTALLATION METHOD "B"
NO SCALE




CHANNEL TERMINATION PLAN
NO SCALE




CHANNEL TERMINATION
NO SCALE



CHANNEL BLANKET END OF ROLL OVERLAP
NO SCALE



STEP 1



STEP 2


CHANNEL TRENCHING METHOD "A"
NO SCALE

Curlex® CL Staple Pattern Guide

For 8 ft wide Curlex CL Erosion Control Blankets
Adjust horizontal staple spacing for 4 ft and 16 ft wide Curlex CL Erosion Control Blankets



| Application | Channel |
|----------------|--|
| | ≤ 1.80 lb/ft ² (86 Pa) Shear Stress |
| | ≤ 7.3 ft/sec (2.2 m/sec) Velocity |
| Staple Pattern | C |

⊙ = Staple Placement




Notes:

1. Recommended staples are a minimum 4 in biodegradable E-Staple®, as provided by American Excelsior Company, or 6 in wire for cohesive soils and 6 in biodegradable E-Staple®, as provided by American Excelsior Company, or 8 in wire for non-cohesive soils.
2. For best results insert staples so heads are parallel to the flow of water.
3. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below.



STEP 1



STEP 2

CHANNEL TRENCHING METHOD "B"
NO SCALE

