




American Excelsior Company Channel Application Guide



<sup>a</sup> Verify design shear stress requirements because there are not many channels that require a vegetated shear >575 Pa.

<sup>b</sup> Functional longevity varies by region because of differences in climatic conditions.

**Notes:**


- Several American Excelsior Company (AEC) RECPs are available with 100% biodegradable, FibreNet™ netting.
- If the goal of the project is to have netting gone within 90 days, then Curlex NetFree or AEC's white QuickMow™ netting should be used.

**Remember to always ask these three questions:**

- What is the actual design shear stress for the channel?
- How long do I need/want the product to last?
- What is the soil type?

**This document is only a guide. Complete Technical Support, including free and easy to use ErosionWorks design software, is available at [www.Curlex.com](http://www.Curlex.com) or contact AEC for specific project recommendations.**

**American Excelsior Company RECP Channel Selection Guide (Unvegetated)**



**American Excelsior Company RECP Channel Selection Guide (Vegetated)**

