



NOTES:


1. SEE TriNet® RECYCLEX® SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.




CHANNEL TERMINATION PLAN
NO SCALE




CHANNEL TERMINATION
NO SCALE




CHANNEL INSTALLATION METHOD "A"
NO SCALE



SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE



CHANNEL INSTALLATION METHOD "B"
NO SCALE




CHANNEL TRM END OF ROLL OVERLAP
NO SCALE

TriNet® Recyclex® Turf Reinforcement Mat (TRM) Staple Pattern Guide

For 8 ft wide TriNet TRM
Adjust horizontal staple spacing for 16ft wide TRM



Application	Channel	
	≤ 3.0 lb/ft² (144 Pa) Shear Stress ≤ 12.0 ft/sec (3.66 m/sec) Velocity	≤ 14 lb/ft² (670 Pa) Shear Stress ≤ 25.0 ft/sec (6.1 m/sec) Velocity
Staple Pattern	B	C

● = Staple Placement




Notes:

1. For cohesive soil use a 6 in wire staple and for non-cohesive soil use an 8 in wire staple.
2. For best results insert staples so heads are parallel to the flow of water.
3. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below.



CHANNEL TRENCHING METHOD "A"
NO SCALE



CHANNEL TRENCHING METHOD "B"
NO SCALE

