



NOTES:
 1. SEE CURLEX® NETFREE™ SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.

CHANNEL DETAIL
 NO SCALE


SIDE SEAM OVERLAP STAPLE DETAIL
 NO SCALE





CHANNEL INSTALLATION METHOD "A"
 NO SCALE




CHANNEL BLANKET END OF ROLL OVERLAP
 NO SCALE




CHANNEL INSTALLATION METHOD "B"
 NO SCALE



CHANNEL TRENCHING METHOD "A"
 NO SCALE



CHANNEL TERMINATION PLAN
 NO SCALE




CHANNEL TERMINATION
 NO SCALE



Curlex® NetFree™ Staple Pattern Guide

Application	Channel $\leq 1.0 \text{ lb/ft}^2 (48 \text{ Pa})$ Shear Stress $\leq 3.0 \text{ ft/sec (0.9 m/sec)}$ Velocity
Staple Pattern	B

● = Staple Placement



Notes:
 1. Recommended staples include 6 in long steel or 4 in long 100% biodegradable E-Staple®, as provided by American Excelsior Company, for cohesive soils and 8 in long steel staples or 6 in long 100% biodegradable E-staples®, as provided by American Excelsior Company, for non-cohesive soils.
 2. Staples shall be placed on a stitch line and for best results insert staples so heads are parallel to the flow of water.
 3. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below:
 Critical channel points are circled.



CHANNEL TRENCHING METHOD "B"
 NO SCALE

