







NOTES:
1. SEE AEC PREMIER COCONUT™ SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.




AEC Premier Coconut™ Staple Pattern Guide



For 8 ft wide AEC Premier Coconut Erosion Control Blankets

Application	Channel
Staple Pattern	B

● = Staple Placement



- Notes:**
1. Recommended staples are minimum 4 in biodegradable E-Staple®, as provided by American Excelsior Company, or 6 in wire for cohesive soils and 6 in biodegradable E-staple®, as provided by American Excelsior Company, or 8 in wire for non-cohesive soils.
 2. For best results, insert staples so heads are parallel to the flow of water.
 3. For additional pull-out resistance, consider using TL-TA2 Gripple twist anchors for tough/cohesive soils or TL-TA1 Gripple twist anchors for moderate/non-cohesive soils.
 4. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below.



American Excelsior Company®
Earth Science Division

AMERICAN EXCELSIOR COMPANY
ARLINGTON, TEXAS

SHEET DESCRIPTION
AEC PREMIER COCONUT™ CHANNEL APPLICATION DETAIL

DATE 11/22/23
SCALE NONE

DRAWN BY
PROJECT NO.
SHEET NO. 13