


NOTES:


1. SEE TriNet[®] COCONUT SLOPE APPLICATION DETAIL SHEET FOR PROPER SLOPE INSTALLATION.

CHANNEL DETAIL
NO SCALE (1/35)


SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE (6/35)




CHANNEL INSTALLATION METHOD "A"
NO SCALE (2/35)




CHANNEL INSTALLATION METHOD "B"
NO SCALE (3/35)




CHANNEL BLANKET END OF ROLL OVERLAP
NO SCALE (7/35)





CHANNEL TRENCHING METHOD "A"
NO SCALE (8/35)



CHANNEL TERMINATION PLAN
NO SCALE (4/35)



CHANNEL TERMINATION
NO SCALE (5/35)




CHANNEL TRENCHING METHOD "B"
NO SCALE (9/35)

TriNet[®] Coconut Turf Reinforcement Mat (TRM) Staple Pattern Guide


For 8 ft wide TriNet TRM
Adjust horizontal staple spacing for 16ft wide TRM

Application	Channel	
	≤ 3.0 lb/ft ² (144 Pa) Shear Stress ≤ 12.0 ft/sec (3.66 m/sec) Velocity	≤ 12 lb/ft ² (575 Pa) Shear Stress ≤ 20.0 ft/sec (6.1 m/sec) Velocity
Staple Pattern	B	C

● = Staple Placement



3.3 Staples/yd²



3.7 Staples/yd²

Notes:

1. For tough/cohesive soil, use TL-TA2 Gripple twist anchors; for moderate/non-cohesive soil, use TL-TA1 Gripple twist anchors.
2. Adjust staple pattern so staples are placed in critical channel points (e.g. slope interface, channel bottom) as illustrated below:

Critical channel points are circled.

