




SLOPE DETAIL
NO SCALE




OVER SLOPE CREST METHOD
NO SCALE


DO NOT NEED TO TRENCH BLANKET IF IT CAN BE EXTENDED A MINIMUM OF 3'-0" OVER THE CREST OF THE SLOPE.





SLOPE TRENCHING METHOD "A"
NO SCALE



END ROLL OVERLAP
NO SCALE



BOTTOM OF SLOPE TERMINATION
NO SCALE






SLOPE TRENCHING METHOD "B"
NO SCALE

AEC Premier Straw® Staple Pattern Guide


For 8 ft wide AEC Premier Straw Erosion Control Blankets
Adjust horizontal staple spacing for 16 ft wide Premier Straw Erosion Control Blankets

Application	Slope		
	≤ 4H:1V	≤ 3H:1V	≤ 2H:1V
Staple Pattern	A	B	C



Notes:

1. Recommended staples are minimum 4 in biodegradable E-Staple®, as provided by American Excelsior Company, or 6 in wire for cohesive soils and 6 in biodegradable E-staple®, as provided by American Excelsior Company, or 8 in wire for non-cohesive soils.
2. For best results insert staples so heads are parallel to the flow of water.



SIDE SEAM OVERLAP STAPLE DETAIL
NO SCALE

